



60-BY/660-BY


Place this manual with personnel responsible for maintenance of this valve



Installation



Operation



Maintenance



SHEET 1 OF 3

				GLA-VAL GO. NEWPORT BEACH, CALIFORNIA 60-BY/660-BY 211853	REV
			TYPE OF	OF VALVE AND MAIN FEATURES DESIGN	
				BOOSTER PUMP CONTROL VALVE WITH HY-CHECK AND	3-5-18
		Ш		HIGH CAPACITY CSM11 CHK'D VL	3-5-18
				(4" AND LARGER ONLY) APV'D VL	3-5-18
					0 0 10
				—— — NOT FURNISHED BY CLA-VAL CO. — — — OPTIONAL FEATURES	
	18		P1:	7A 2 2 3 4 4 4 4 4 4 4 4 4 4	P2 (\overline{\nabla})
DATE	3-5-18				В
à	A V				
CAD REVISION RECORD — DO NOT REVISE MANUALLY DESCRIPTION	3)			INLET OUTLET	
ĕ	26663)		ITEM NO.	BASIC COMPONENTS QTY	
8	26		1	100-04 HY-CHECK (60-BY) MAIN VALVE	
[[8			100-23 HY-CHECK (660-BY) MAIN VALVE	
	PRODUCTION (ECO		2	CSM11-A2-2 SOLENOID CONTROL (HC) 1	
[照[3	X105LCW LIMIT SWITCH ASSEMBLY 1	
			4	CDC CHECK VALVE 1	
<u> </u> ≝	Ιž		5	CDC/CSC CHECK VALVE 1	
اچ	RO		6	CK2 COCK (ISOLATION VALVE) 1	
S			7	CNA NEEDLE VALVE 2 2	
	FOR			OPTIONAL FEATURE SUFFIX ADDED TO CATALOG NUMBER	
			Α	X46A FLOW CLEAN STRAINER 1	
	SEI		В	CK2 COCK (ISOLATION VALVE) 3	
	EA		Р	X141 PRESSURE GAUGE ASSEMBLY 3	
	RELEASED		Υ	X43 "Y" STRAINER 1	
<u> </u>	_	H			
			E DDODEDTA	TY OF CLA_VALOO AND SAME AND CODES MADE THEREFOR IF ANY SHALL BE RETIRINED TO IT IDON DEMAND DELINERY AND DISCUSSIBLE HEREOGE ARE MADE SOLELY LIBON CONDITION	N THAT THE CASE

								ELI 2 OF	3		
			CIΔ-V	ALCO. NEWPO	RT BEACH, CALIFORNIA	CATALOG NO. 60-BY/660-BY	DRAWING	NO. 11853	REV		
			ALVE AND MAIN FEATU	RES			DESIGN	11000			
		B	BOOSTER PUN	IP CONTROL VAL		DRAWN	AV	3-5-18			
\vdash		$\{ \ \cdot \ $		HIGH CAPACI		CHK'D	VL	3-5-18			
				(4" AND LARG	JER UNLY)		APV'D	VL	3-5-18		
					<u>OPERATING</u>	DATA					
		Ι.	SOLENOID (THAT CHAN THIS APPLI	IGES POSITIÓN V ES OR RELIEVES	A DIRECT AC WHEN THE CO PRESSURE IN	TING 4-WAY SOLE IL IS ENERGIZED ON THE COVER CHA TON SHOWN IN TH	OR DE- AMBER	-ENERGIZ OF THE			
			TABLE:		SOLENOID CON	TROL (2)					
				POSITION	PORTS CONNECTED	MAIN VALVE (1) POSITION					
				ENERGIZED	"S" & "1" "2" & "D"	OPEN					
				DE-ENERGIZED	"S" & "2" "1" & "D"	CLOSED					
1	UAIE	II.	TO MANUAL	ATED ON TOP OF	HE SOLENOID, F THE COIL EI	PRESS DOWN ON NCLOSURE AND TU	JRN CI	LOCKWISE			
╽┝	£ 8		KNURLED K		1/4 TURN A	O ELECTRICAL CO ND THE KNURLED		•	HE		
DO NOT REVISE MANUALLY		III.	CHECK VAL THE MAIN V PRESSURE REVERSE FI THIS PERMI	VE FEATURE: VALVE (1) HAS EXCEEDS INLET LOW. CHECK VA TS OUTLET PRES	AN INTEGRAL PRESSURE, T ALVE (5) OPE SSURE TO FLO	CHECK FEATURE. HE MAIN VALVE C NS AND CHECK V DW INTO THE MAIN LY MOVES TO THE	LOSES ALVE (N VAL)	PREVEN (4) CLOS VE COVER	TING ES. R		
CAD REVISION RECORD — DO NOT REVISE	DESCRIPTION	IV.	CHAMBER AND THE DIAPHRAGM ASSEMBLY MOVES TO THE DOWN POSITION. IV. CLOSING SPEED CONTROL FEATURE: NEEDLE VALVE (7A) CONTROLS THE CLOSING SPEED OF THE MAIN VALVE. TURN THE ADJUSTING STEM CLOCKWISE TO MAKE THE MAIN VALVE CLOSE SLOWER. DO NOT CLOSE VALVE (7A) COMPLETELY OR THE MAIN VALVE WILL NOT CLOSE. (SUGGESTED INITIAL SETTING OF NEEDLE VALVE IS 1/4 TO 1/2 TURN OPEN.)								
	SEE SHEET 1	V.	NEEDLE VA TURN THE SLOWER. DO	ADJUSTIŃG STEM O NOT CLOSE V	ROLS THE OPE M CLOCKWISE ALVE (7B) CC	ENING SPEED OF T TO MAKE THE MA OMPLETELY OR THE	IN VAI E MAIN	LVE OPEN I VALVE	١		

LTR

1/2 TURN OPEN.)

SHEET 3 OF 3

Т			CLA-VAL CO. NEWPORT BEACH, CALIFORNIA	CATALOG NO.	DRAWING N		REV
		TYPE OF VA	LIVE AND MAIN FEATURES	60-BY/660-BY	DESIGN	1853	_ _
			COOSTER PUMP CONTROL VALVE WITH HY-C	CHECK AND	DRAWN	AV	3-5-18
+			HIGH CAPACITY CSM11 (4" AND LARGER ONLY)		CHK'D	VL	3-5-18
			(4 AND LARGER ONLT)		APV'D	VL	3-5-18
			OPERATING DATA-	<u>CONTINUED</u>			
		VI.	SWITCH ASSEMBLY FEATURE: SWITCH ASSEMBLY (3) IS ACTUATED BY A THE MAIN VALVE STEM. THE SWITCH ASS TO ACTUATE A SINGLE-POLE DOUBLE-TH VALVE IS ALMOST CLOSED. WHEN THE M THE SPRING LOADED SWITCH ACTUATING RETURNS THE SWITCH TO ITS NORMAL PO	SEMBLY IS FACT(IROW SWITCH WH MAIN VALVE STAR LEVER IS RELEAS	DRY AD EN THE PTS TO	JUSTED MAIN OPEN,	ТО
		VII.	OPTIONAL FEATURE OPERATING DATA:				
			SUFFIX A (FLOW CLEAN STRAINER): A SELF-CLEANING STRAINER IS INSTALLED BOSS WHICH PROTECTS THE PILOT SYSTE				DY
			SUFFIX B (ISOLATION VALVES): CK2 COCKS (B) ARE USED TO ISOLATE T PRESSURE. THESE VALVES MUST BE OPE				
<u> </u>		<u> </u>	SUFFIX P (PRESSURE GAUGE):				
ļ	DAIE		PRESSURE GAUGES (P1), (P2), AND (P3) INLET, OUTLET, AND COVER CONNECTIONS	PROVIDE PRESSI S.	JRE RE	EADING I	N THE
ŀ	5		SUFFIX Y (Y-STRAINER): A Y-PATTERN STRAINER IS INSTALLED IN PROTECT THE PILOT SYSTEM FROM FOREI SCREEN MUST BE CLEANED PERIODICALLY	GN PARTICLES.			
CAD REVISION RECORD — DO NOT REVISE MANUALLY	-	VIII.	CHECK LIST FOR PROPER OPERATION: () SYSTEM VALVES OPEN UPSTREAM ANI () AIR REMOVED FROM THE MAIN VALVE HIGH POINTS. () PERIODIC CLEANING OF STRAINER (Y) FEATURE). () CNA NEEDLE VALVES (7A) AND (7B) () CORRECT VOLTAGE TO SOLENOID CON () MANUAL OPERATOR OF SOLENOID CON () LIMIT SWITCH ASSEMBLY (3) PROPERL () CK2 COCK (6) OPEN DURING NORMAL () CK2 COCKS (B) OPEN (OPTIONAL FEATURE)	D DOWNSTREAM. COVER AND PIL IS RECOMMENDE OPEN AT LEAST ITROL (2). NTROL (2) DISEN LY WIRED. OPERATION.	D (OP ⁻	ΠΟΝΑL URN.	ALL
	SEE SHEE						




Recommended Inspections

Cla-Val recommends that an inspection be performed on our products annually. The inspection should include both a visual and functional test of the main valve/component and the pilot system. The inspection ensures that no damage or premature wear occurred due to velocity, pressure, or foreign matter within the fluid that may have exceeded the valve's design. Please consult the maintenance manual for specific information on the model. Manuals are available for download at Cla-Val.com, as well as contact information for a company representative.

Accurate record-keeping is a best practice for any preventative maintenance program, and Cla-Val strongly recommends this action through an asset management program. Cla-Val provides a free asset management tool, Link2Valves <u>Link2Valves - Cla-Val (cla-val.com)</u>, to assist in preventative maintenance record-keeping and scheduling.



Hy-Check Valve




- Built-in Automatic Check Valve
- Drip Tight, Positive Seating
- Globe or Angle Pattern
- Service Without Removal From Line
- · Every valve factory-tested

The Cla-Val Model 100-04 Hy-Check Valve is a hydraulically operated diaphragm valve with a built-in check feature to prevent return flow. Available in globe or angle pattern, it consists of a body, cover and diaphragm assembly. The diaphragm assembly which is guided top and bottom by a precision machined stem is the only moving part.

A synthetic rubber disc retained on three and one half sides forms a drip-tight seal with the renewable seat when operating pressure is applied above the non-wicking diaphragm. When pressure above the diaphragm is relieved, the valve opens wide. The rate of closing or opening can be controlled by modulating the flow into or out of the cover chamber. When a pressure reversal occurs the split stem will immediately allow the disc retainer assembly to check closed **regardless of the position of the diaphragm.**


The Model 100-04 is used on system applications such as remote control, pressure regulation, solenoid control, etc.; wherever a positive check feature is necessary to prevent reverse flow. Its packless construction and simplicity of design minimizes maintenance and assures a long dependable service life.

Principle of Operation




Full Open Operation

When pressure in the cover chamber is relieved to a zone of lower pressure, the line pressure at the valve inlet opens the valve, allowing full flow.



Tight Closing Operation

When pressure from the valve inlet is applied to the cover chamber, the valve closes drip-tight.



Check Action

When a static condition or pressure reversal occurs, the split stem design allows the valve to instantly check closed. Return flow is prevented regardless of the diaphragm's position.

Note: For optimum operation of built-in check feature, installation with stem vertically up is recommended.

Specifications

Available Sizes

Pattern	Flanged						
Globe	2" - 16" 50 - 400 mm						
Angle	3" - 16" 80 - 400 mm						

Operating Temp. Range

Fluids	
-40° to 180° F -40° to 82° C	

Pressure Ratings (Recommended Maximum Pressure - psi)

Valve Body 8	Cover	Pressure Class					
valve body o	Cover	Fla	Flanged				
Grade	Material	ANSI Standards*	150 Class	300 Class	End‡ Details		
ASTM A536	Ductile Iron	B16.42	250	400	400		
ASTM A216-WCB	Cast Steel	B16.5	285	400	400		
UNS 87850	Bronze	B16.24	225	400	400		

* ANSI standards are for flange dimensions only. Flanged valves are available faced but not drilled.

‡ End Details machined to ANSI B2.1 specifications.

Valves for higher pressure are available; consult factory for details

Materials

Component	Standard Material Combinations					
Body & Cover	Ductile Iron	Cast Steel	Bronze			
Available Sizes (inches)	2" - 16"	2" - 16"	2" - 16"			
Available Sizes (mm)	50 - 400 mm	50 - 400 mm	50 - 400 mm			
Disc Retainer & Diaphragm Washer	Cast Iron Cast Steel		Bronze			
Trim: Disc Guide,	Bronze is Standard					
Seat & Cover Bearing	Stainless Steel is optional					
Disc	Buna-N® Rubber					
Diaphragm	Nylon Reinforced Buna-N® Rubber					
Stem, Nut & Spring	Stainless Steel					
For material options not listed, consult factory.						

Cla-Val manufactures valves in more than 50 different alloys.

Options

Epoxy Coating - suffix KC


This option NSF 61 Listed and FDA approved, fusion bonded epoxy coating is for use with cast iron, ductile iron or steel valves. This coating is resistant to various water conditions, certain acids, chemicals, solvents and alkalies. Epoxy coatings are applied in accordance with AWWA coating specifications C116-03.

Do not use with temperatures above 175° F /80°C.

Viton® Rubber Parts - suffix KB

Optional diaphragm, disc and o-ring fabricated with Viton® synthetic rubber. Viton® is well suited for use with mineral acids, salt solutions, chlorinated hydrocarbons, and petroleum oils; and is primarily used in high temperature applications up to 250°F/120°C. Do not use with epoxy coating above 175°F/80° C.

For assistance in selecting appropriate valve options or valves manufactured with special design requirements, please contact our Regional Sales Office or Factory.



Functional Data Model 100-04

Valve Size		Inches	2	3	4	6	8	10	12	14	16
valve	SIZE	mm.	50	80	100	150	200	250	300	350	400
	Globe	Gal./Min. (gpm.)	54	115	200	440	770	1245	1725	2300	3130
C _V	Pattern	Litres/Sec. (I/s.)	13	27.6	48	105.6	184.8	299	414	552	706
Factor	Angle	Gal./Min. (gpm.)	61	139	240	541	990	1575	2500*	3060*	4200*
	Pattern	Litres/Sec. (I/s.)	14.6	33.4	58	130	238	378	600	734.4	1008
Equivalent	Globe	Feet (ft.)	51	85	116	211	291	347	467	422	503
Length	Pattern	Meters (m.)	15.5	25.9	35.3	64.2	88.6	105.8	142.4	128.6	153.6
of	Angle	Feet (ft.)	40	58	80	139	176	217	222*	238*	247*
Pipe	Pattern	Meters (m.)	12.1	17.8	24.5	42.5	53.6	66.1	67.8	72.7	75.2
К	Globe Pattern		5.6	6.0	5.9	6.2	6.1	5.8	6.1	5.0	4.6
Factor	An	gle Pattern	4.4	4.1	4.1	4.1	3.7	3.6	2.9	2.8	2.6
		Fl. Oz	_	_	_	_	_	_	_	_	_
Liquid Displa Cover Chamb		U.S. Gal.	0.3	.08	.17	.53	1.26	2.51	4.0	6.5	9.6
Valve O		ml	121	303	643	_	_	_	_	_	_
		Litres	_	_	_	2.0	4.8	9.5	15.1	24.6	36.2

^{*}Estimated

C_V Factor

Formulas for computing C_V Factor, Flow (Q) and Pressure Drop (AP):

$$C_V = \frac{Q}{\sqrt{\triangle P}}$$
 $Q = C_V \sqrt{\triangle P}$ $\triangle P = \left(\frac{Q}{C_V}\right)^2$

K Factor (Resistance Coefficient)
The Value of K is calculated from the formula: $K = \frac{894d}{C_V^2}$ (U.S. system units)

Equivalent Length of Pipe

Equivalent lengths of pipe (L) are determined from the formula: $L = \frac{Kd}{12f}$ (U.S. system units)

Fluid Velocity

Fluid velocity can be calculated from the following formula: $V = \frac{.4085 \text{ Q}}{d^2}$ (U.S. system units)

Where:

C_V = U.S. (gpm) @ 1 psi differential at 60° F water

= (l/s) @ 1 bar (14.5 PSIG) differential at 15°C water

d = inside pipe diameter of Schedule 40 Steel Pipe (inches)

f = friction factor for clean, new Schedule 40 pipe (dimensionless) (from Cameron Hydraulic Data, 18th Edition, P 3-119)

K = Resistance Coefficient (calculated)


L = Equivalent Length of Pipe (feet)

Q = Flow Rate in U.S. (gpm) or (I/s)


= Fluid Velocity (feet per second) or (meters per second)

 $\triangle \mathbf{P}$ = Pressure Drop in (psi) or (bar)

Model 100-04 Flow Chart (Based on normal flow through a wide open valve)



Cla-Val 100-04 Hy-Check Main Valve Dimensions



Valve Size (Inches)	2	3	4	6	8	10	12	14	16
A 150 ANSI	9.38	12.00	15.00	20.00	25.38	29.75	34.00	39.00	41.38
AA 300 ANSI	10.00	13.25	15.62	21.00	26.38	31.12	35.50	40.50	43.50
B Diameter	6.62	9.12	11.50	15.75	20.00	23.62	28.00	32.75	35.50
C Maximum	6.50	8.19	10.62	13.38	16.00	17.12	20.88	24.19	25.00
D 150 ANSI	4.75	6.00	7.50	10.00	12.69	14.88	17.00	19.50	20.69
DD 300 ANSI	5.00	6.38	7.81	10.50	13.19	15.56	17.75	20.25	21.75
E	1.50	2.56	3.19	4.31	5.31	9.25	10.75	12.62	15.50
F 150 ANSI	2.50	3.75	4.50	5.50	6.75	8.00	9.50	10.50	11.75
FF 300 ANSI	3.25	4.13	5.00	6.25	7.50	8.75	10.25	11.50	12.75
G 150 ANSI	3.25	4.00	5.00	6.00	8.00	8.62	13.75	14.88	15.69
GG 300 ANSI	3.25	4.38	5.31	6.50	8.50	9.31	14.50	15.62	16.50
H NPT Body Tapping	0.38	0.50	0.75	0.75	1.00	1.00	1.00	1.00	1.00
J NPT Cover Center Plug	0.50	0.50	0.75	0.75	1.00	1.00	1.25	1.50	2.00
K NPT Cover Tapping	0.38	0.50	0.75	0.75	1.00	1.00	1.00	1.00	1.00
Stem Travel	0.60	.080	1.10	1.70	2.30	2.80	3.40	4.00	4.50
Approx. Ship Weight (lbs)	35	70	140	285	500	780	1165	1500	2265
Valve Size (mm)	50	80	100	150	200	250	300	350	400
A 150 ANSI	238	305	381	508	645	756	864	991	1051
AA 300 ANSI	254	337	397	533	670	790	902	1029	1105
B Diameter	168	232	292	400	508	600	711	832	902
C Maximum	165	208	270	340	406	435	530	614	635
D 150 ANSI	121	152	191	254	322	378	432	495	526
DD 300 ANSI	127	162	200	267	335	395	451	514	552
E	38	65	81	109	135	235	273	321	394
F 150 ANSI	76	95	114	140	171	203	241	267	298
FF 300 ANSI	83	105	127	159	191	222	260	292	324
G 150 ANSI	83	102	127	152	203	219	349	378	399
GG 300 ANSI	89	111	135	165	216	236	368	397	419
H NPT Body Tapping	0.38	0.50	0.75	0.75	1.00	1.00	1.00	1.00	1.00
J NPT Cover Center Plug	0.50	0.50	0.75	0.75	1.00	1.00	1.25	1.50	2.00
K NPT Cover Tapping	0.38	0.50	0.75	0.75	1.00	1.00	1.00	1.00	1.00
Stem Travel	15	20	28	43	58	71	86	102	114

Service

Approx. Ship Weight (kgs)

16

32

. 0:

Cla-Val Control Valves operate with maximum efficiency when mounted in horizontal piping with the main valve cover UP, however, other positions are acceptable. Due to component size and weight of 8 inch and larger valves, installation with cover UP is advisable. We recommend isolation valves be installed on inlet and outlet for maintenance. Adequate space above and around the valve for service personnel should be considered essential. A regular maintenance program should be established based on the specific application data. However, we recommend a thorough inspection be done at least once a year. Consult factory for specific recommendations.

129

64



227

354


528

726

1027

600 Series

Hy-Check Valve




- Built-in Automatic Check Valve
- Improved Flow Characteristics
- Drip Tight, Positive Seating
- · Globe or Angle Pattern
- · Packless Construction

The Cla-Val Model 100-23 Hy-Check Valve is a hydraulically operated diaphragm valve with a built-in check feature to prevent return flow. Available in a globe or angle pattern, it consists of three parts: body, cover and diaphragm assembly. The only moving part is the diaphragm assembly which is guided top and bottom by a precision machined stem.

When operating pressure is applied above the non-wicking diaphragm, a synthetic rubber disc retained on three and one-half sides forms a drip-tight seal with the renewable seat. When pressure above the diaphragm is relieved the valve opens wide. The rate of closing or opening can be controlled by modulating the flow into or out of the diaphragm chamber. When a pressure reversal occurs the split valve stem will allow the disc retainer assembly to check closed **regardless of the position of the diaphragm.**


The Model 100-23 is used on system applications requiring remote control, pressure regulation, solenoid control, rate of flow control, liquid level control, or wherever a positive check feature is necessary to prevent reverse flow.

Principle of Operation




Full Open Operation

When pressure in the cover chamber is relieved to a zone of lower pressure, the line pressure at the valve inlet opens the valve, allowing full flow.



Tight Closing Operation

When pressure from the valve inlet is applied to the cover chamber, the valve closes drip-tight.



Check Action

When a static condition or pressure reversal occurs, the split stem design allows the valve to instantly check closed. Return flow is prevented regardless of the diaphragm's position.

Cla-Val 100-23 Hy-Check Main Valve Specifications

Pressure Ratings (Recommended Maximum Pressure - psi)

* ANSI standards are for flange dimensions only.

Flanged valves are available faced but not drilled. Valves for higher pressure are available; consult factory for details

ANSI

Standards*

B16.42

B16.5

B16.24

Pressure Class

Flanged

150

Class

250

285

225

300

Class

400

400

400

Available Sizes

Grade

ASTM A216-WCB

ASTM A536

UNS 87850

Note:

Valve Body & Cover

	-
Pattern	Flanged
Globe (inches)	3" - 24"
Globe (mm)	80 - 600 mm
Angle (inches)	6", 8"
Angle (mm)	150 and 200 mm

Material

Ductile Iron

Cast Steel

Bronze

Operating Temp. Range

Fluids
-40° to 180° F -40° to 82° C



6" Globe, Flanged





6" Angle, Flanged

Materials

Component	Standard Material Combinations					
Body & Cover	Ductile Iron	Cast Steel	Bronze			
Available Sizes (inches)	3" - 24"	3" - 16"	3" - 16"			
Available Sizes (mm)	80 - 600 mm	80 - 400 mm	80 - 400 mm			
Disc Retainer & Diaphragm Washer	Cast Iron Cast Steel		Bronze			
Trim: Disc Guide, Seat & Cover Bearing	Bronze is Standard Stainless Steel is optional					
Disc	Buna-N® Rubber					
Diaphragm	Nylon Reinforced Buna-N® Rubber					
Stem, Nut & Spring Stainless Steel						
For material entiage not listed consult factory						

For material options not listed, consult factory.

Cla-Val manufactures valves in more than 50 different alloys.



12" Globe, Flanged

Options

NSF/ANSI 61 Fusion Bonded Epoxy Coating - suffix KC

The fusion bonded epoxy coating option is for use with cast iron, ductile iron or steel valves. This coating is resistant to various water conditions, certain acids, chemicals, solvents and alkalies. epoxy coatings are applied in accordance with AWWA coating specifications C116-03. Do not use with temperatures above 175° F.



please contact our Regional Sales Office or Factory.

Viton® Rubber Parts - suffix KB

Optional diaphragm, disc and o-ring fabricated with Viton® synthetic rubber. Viton® is well suited for use with mineral acids, salt solutions, chlorinated hydrocarbons, and petroleum oils; and is primarily used in high temperature applications up to 250° F. Do not use with epoxy coating above 175°F.



20" Globe, Flanged

Cla-Val 100-23 Hy-Check Main Valve Functional Data

70	Inches	3	4	6	8	10	12	14	16	18	20	24
26	mm.	80	100	150	200	250	300	350	400	460	500	600
Globe	Gal./Min. (gpm.)	62	136	229	480	930	1458	1725	2110	3250*	3400*	4020
Pattern	Litres/Sec. (I/s.)	15	32.5	55	115	223	350	414	506	705	816	965
Angle	Gal./Min. (gpm.)	_	135	233	545	_	_	_	_	_	_	_
Pattern	Litres/Sec. (I/s.)	_	32	56	132	_	_	_	_	_	_	_
Globe	Feet (ft.)	293	251	777	748	621	654	750	977	983	1125	3005
Pattern	Meters (m.)	89.3	76.4	237.1	228.1	189.5	199.4	228.7	298.1	299.9	343.2	916.6
Angle	Feet (ft.)	_	254	751	580	_	_	_	_	_	_	_
Pattern	Meters (m.)	_	77.6	229	176.9	_	_	_	_	_	_	_
	Globe Pattern	20.6	12.7	23.1	15.7	10.4	8.5	8.9	10.2	6.9	9.7	14.5
	Angle Pattern	_	12.9	22.3	12.2	_	_	_	_	_	_	_
	Fl. Oz	_	_	_	_	_	_	_	_	_	_	_
ed from	U.S. Gal.	0.32	.08	.17	.53	1.26	2.51	4.0	4.0	9.6	9.6	9.6
ns	ml	_	_	_	_	_	_	_	_	_	_	_
	Litres	.12	.30	.64	2.0	4.8	9.5	15.1	15.1	36.2	36.2	36.2
	Pattern Angle Pattern Globe Pattern Angle Pattern Angle Pattern	mm. Globe Gal./Min. (gpm.) Pattern Litres/Sec. (l/s.) Angle Pattern Litres/Sec. (l/s.) Globe Pettern Meters (m.) Angle Pattern Meters (m.) Globe Pattern Angle Pattern Angle Pattern Globe Pattern Angle Pattern Jed from Fl. Oz U.S. Gal. ml	Mm. 80 Gal./Min. (gpm.) 62 Angle Pattern Litres/Sec. (l/s.) 15 Cal./Min. (gpm.) — Litres/Sec. (l/s.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) — Cal./Min. (gpm.) Cal./Min. (gpm.) — Cal./Min. (gpm.) Cal./Min. (gpm.) Cal./Min. (gpm.) Cal./Min. (gpm.) Cal./Min. (gpm.)	Main	Main	Mail	Main	Main	Marcon M	Marcon M	Marcon M	Marcon M

^{*}Estimated

C_V Factor

Formulas for computing C_V Factor, Flow (Q) and Pressure Drop (\blacktriangle P):

$$C_{V} = \frac{Q}{\sqrt{\triangle P}}$$
 $Q = C_{V} \sqrt{\triangle P}$ $\triangle P = \left(\frac{Q}{C_{V}}\right)^{2}$

K Factor (Resistance Coefficient)

The Value of K is calculated from the formula: $K = \frac{894d}{C_V^2}$ (U.S. system units)

Equivalent Length of Pipe

Equivalent Lengths of pipe (L) are determined from the formula: $L = \frac{Kd}{12 \text{ f}}$ (U.S. system units)

Fluid Velocity

Fluid velocity
Fluid velocity can be calculated from the following formula: $V = \frac{.4085 \text{ Q}}{\text{d}^2}$ (U.S. system units)

Where:

 $\mathbf{C}_{\mathbf{V}} = \text{U.S. (gpm)} @ 1 \text{ psi differential at } 60^{\circ} \text{ F water}$

= (I/s) @ 1 bar (14.5 PSIG) differential at 15° C water

d = inside pipe diameter of Schedule 40 Steel Pipe (inches)

 f = friction factor for clean, new Schedule 40 pipe (dimensionless) (from Cameron Hydraulic Data, 18th Edition, P 3-119)

K = Resistance Coefficient (calculated)


L = Equivalent Length of Pipe (feet)

Q = Flow Rate in U.S. (gpm) or (l/s)


V = Fluid Velocity (feet per second) or (meters per second)

 $\triangle \mathbf{P}$ = Pressure Drop in (psi) or (bar)

Model 100-23 Flow Chart (Based on normal flow through a wide open valve)



Cla-Val 100-23 Hy-Check Main Valve Dimensions



Valve Size (Inches)	3	4	6	8	10	12	14	16	18	20	24
A 150 ANSI	10.25	13.88	17.75	21.38	26.00	30.00	34.25	35.00	42.12	48.00	48.00
AA 300 ANSI	11.00	14.50	18.62	22.38	27.38	31.50	35.75	36.62	43.63	49.62	49.75
B Diameter	6.62	9.12	11.50	15.75	20.00	23.62	27.47	28.00	35.44	35.44	35.44
C Maximum	7.00	8.62	11.62	15.00	17.88	21.00	20.88	25.75	25.00	31.50	31.50
D 150 ANSI	_	6.94	8.88	10.69	_	_	_	_	_	_	_
DD 300 ANSI	_	7.25	9.38	11.19	_	_	_	_	_	_	_
E 150 ANSI	_	5.50	6.75	7.25	_	_	_	_	_	_	_
EE 300 ANSI	_	5.81	7.25	7.75	_	_	_	_	_	_	_
F 150 ANSI	3.75	4.50	5.50	6.75	8.00	9.50	11.00	11.75	15.88	14.56	17.00
FF 300 ANSI	4.12	5.00	6.25	7.50	8.75	10.25	_	12.75	15.88	16.06	19.00
H NPT Body Tapping	.375	0.50	0.75	0.75	1.00	1.00	1.00	1.00	1.00	1.00	1.00
J NPT Cover Center Plug	0.50	0.50	0.75	0.75	1.00	1.00	1.25	1.25	2.00	2.00	2.00
K NPT Cover Tapping	.375	0.50	0.75	0.75	1.00	1.00	1.00	1.00	1.00	1.00	1.00
Stem Travel	0.60	0.80	1.10	1.70	2.30	2.80	3.40	3.40	4.50	4.50	4.50
Approx. Ship Weight (lbs)	45	85	195	330	625	900	1250	1380	2365	2551	2733
Approx. X Pilot System	13.00	15.00	27.00	30.00	33.00	36.00	36.00	41.00	40.00	46.00	55.00
Approx. Y Pilot System	10.00	11.00	18.00	20.00	22.00	24.00	26.00	26.00	30.00	30.00	30.00
Approx. Z Pilot System	10.00	11.00	18.00	20.00	22.00	24.00	26.00	26.00	30.00	30.00	30.00

Valve Size (mm)	80	100	150	200	250	300	350	400	450	500	600
A 150 ANSI	260	353	451	543	660	762	870	889	1070	1219	1219
AA 300 ANSI	279	368	473	568	695	800	908	930	1108	1260	1263
B Diameter	168	232	292	400	508	600	698	711	900	900	900
C Maximum	178	219	295	381	454	533	530	654	635	800	800
D 150 ANSI	_	176	226	272	CF*						
DD 300 ANSI	_	184	238	284	CF*						
E 150 ANSI	_	140	171	184	CF*						
EE 300 ANSI	_	148	184	197	CF*						
F 150 ANSI	95	114	140	171	203	241	279	298	403	370	432
FF 300 ANSI	105	127	159	191	222	260	_	324	403	408	483
H NPT Body Tapping	0.38	0.50	0.75	0.75	1.00	1.00	1.00	1.00	1.00	1.00	1.00
J NPT Cover Center Plug	0.50	0.50	0.75	0.75	1.00	1.00	1.25	1.25	2.00	2.00	2.00
K NPT Cover Tapping	0.38	0.50	0.75	0.75	1.00	1.00	1.00	1.00	1.00	1.00	1.00
Stem Travel	15	20	28	43	58	71	86	86	86	114	114
Approx. Ship Weight (kgs)	20	39	89	150	284	409	568	627	681	1157	1249
Approx. X Pilot System	330	381	686	762	838	914	914	1041	1016	1168	1397
Approx. Y Pilot System	254	279	457	508	559	610	660	660	762	762	762
Approx. Z Pilot System	254	279	457	508	559	610	660	660	762	762	762

For assistance in selecting appropriate valve options or valves manufactured with special design requirements, please contact our Regional Sales Office or Factory.

Service and Installation


Cla-Val Control Valves operate with maximum efficiency when mounted in horizontal piping with the main valve cover UP, however, other positions are acceptable. Due to component size and weight of 10 inch and larger valves, installation with cover UP is advisable. We recommend isolation valves be installed on inlet and outlet for maintenance. Adequate space above and around the valve for service personnel should be considered essential. A regular maintenance program should be established based on the specific application data. However, we recommend a thorough inspection be done at least once a year. Consult factory for specific recommendations.





CSM-11

Solenoid Control



Item	Description	Item	Description
1	Mounting Bracket	7	Solenoid Assy.
5	Mechanical Parts Assy.		(See table other side)
5-2	Housing	8	Cover
5-3	Spring	9	Manual Operator Assy.
5-4	Guide	9-1	Housing, Manual Operator
5-5	Side Housing	9-2	Plunger
5-6	Cap Screw 1/4'	9-3	Pin, groove-3/8"
5-7	Lever Arm	9-4	"O"- Ring
5-8	Lever Screw	9-5	Spring, Manual Operator
5-9	Stem Assy. (Solenoid)	9-6	Gasket, Manual Operator
5-10	Distributor Gasket	10	Machine Screw Fil. Hd.
5-11	Machine Screw, RDH		10/32 x 5/8 (4 reqd)
	(6/32 x 1 1/4 - 6 reqd.)		
5-12	Distributor (CSM11-A2-2)		Lockwasher
5-13	Disc Assy.	11	Machine Screw Fil. Hd.
5-14	Spring (Disc Assy.)	12	
5-15	Thrust Washer		
5-16	"O"- Ring		
5-17	Stem Assy. (Pilot)	13	Lockwasher
6	Spacer Gasket	14	Coil only: (See table other
			side)
		15	Nameplate
		16	Hex Nut, Jam 1-14 UNS

When ordering parts, please specify:

All Nameplate Data
 Part Description
 Item Number
 Part Material

Recommended Spare Pilot valve sub-assembly (Part of item 5) for model CSM11-A2-2, Standard materials, P/N 18053K

	-	CSMII CONTR	OL ASSEMBLY	,		SOLENOID ASS	EMBLY & COILS
	CSMI	I-A2-2	CSMII-N2-4	CSMII-CZ2-4	CSMII-CQ2-4		
	STANDARD	SEA-WATER SERVICE	STANDARD	STANDARD	STANDARD		
VOLTAGE	STOCK No.	STOCK No.	STOCK No.	STOCK No.	STOCK No.	SOLENOID PART No.	COIL PART No.
24/60 Hz	10023-01J	_	10031-01B	10039-01E	10038-01G	87573-01A	73342J
115/60 Hz	10023-02G	10046-01K	10031-02K	10039-02C	10038-02E	_	_
120/60 Hz	10023-02G	10046-01K	10031-02K	10039-02C	10038-02E	87573-02J	73343G
208/60 Hz	10023-03E	_	10031-03H	10039-03A	10038-03C	87573-03G	73344E
230/60 Hz	10023-04C	_	10031-04F	10039-04J	_	_	_
240/60 Hz	10023-04C	_	10031-04F	10039-04J	10038-04A	87573-04E	73345B
440/60 Hz	10023-09B	_	10031-09E	10039-09H	10038-09K	87573-09D	82542C
460/60 Hz	10023-05K	_	10031-05C	10039-05F	_	_	_
480/60 Hz	10023-05K	_	10031-05C	10039-05F	10038-05H	87573-05B	73346K
110/50 Hz	10023-06H	_	10031-06A	10039-06D	10038-06K	87573-06K	73347H
220/50 Hz	10023-07F	_	10031-07J	10039-07B	10038-07D	87573-07H	73348F
240/50 Hz	10023-08D	_	10031-08G	10039-08K	10038-08B	87573-08F	73349D

The solenoid is rated for continuous duty. It can be held energized continuously in normal ambient temperatures without overheating. Solenoid overheating is often due to over voltage conditions. AC voltage solenoids should not be used with less than 85% of rated voltage.

Solenoid Protection

If a solenoid is mechanically blocked in the energized position the coil soon burns out. Protect it with a "slow blow" fuse with an ampere rating of 1.5 times the solenoid "holding" current shown. Solenoid ratings are based on 115 VAC where holding current is 0.6 amp and solenoid VA rating is 69 volt amperes. Current for other voltages is inversely proportional to voltage.

Examples: A.) Given 115 VAC supply to the solenoid, then 1.5 times .6 = .9 Amp. Select one amp slow blow fuse. B.) Given 24 VAC supply to the solenoid, then 1.5 times 2.88 = 4.32 Amp. Select 4.5 Amp slow blow fuse. C.) Given 240 VAC supply to the solenoid, then 1.5 times 0.288 = 0.432 Amp. Select 0.5 Amp slow blow fuse.

Volts	Amp	eres	Coil Resistance
(AC 60 Hz)	Holding	Inrush	Ohms
24	2.88	25.4	0.5
120	.575	5.1	14.1
208	.330	2.93	40
240	.288	2.54	58
440	.156	1.38	174
480	.143	1.27	233
Volts	Amp	eres	Coil Resistance
(AC 50 Hz)	Holding	Inrush	Ohms
110	.48	4.6	15.7
220	.24	2.3	66
240	.22	2.1	88



$- \frac{\mathsf{X105L}}{\mathsf{X105L2}}$

Limit Switch Assemblies




- · UL/ULC Listed
- Positive Action
- Rugged and Dependable
- Weather Proof or Explosion Proof
- Easy To Adjust


The Cla-Val Model X105L/X105L2 Limit Switch Assembly is a rugged, dependable and positive acting switch assembly actuated by the opening or closing of a Cla-Val control valve on which it is mounted. The single pole, double throw micro switch can be connected either to open or to close an electrical circuit when actuated. By loosening the allen screw on the actuating collar and raising or lowering the collar on the stem, the X105L is easily adjusted to signal that the valve has fully reached the desired position (open or closed).

Installation


Single Pole Double Throw Switch



Double Pole Double Throw Switch



- 1. Remove plug in top of valve cover.
- 2. Screw actuating stem into main valve stem.
- 3. Slip adapter down over stem and screw into place on valve cover.
- 4. Attach micro switch housing and bracket to adapter with jam nut.
- Bring electrical supply circuit into unit through the 1/2" tapping in micro switch housing.
- Adjust switch collars. (Set collar to trip switch after valve is positioned fully open or fully closed)



Actuating Collar Adjustment Minimum Setting


When adjusting actuating collar for proper switch action, a clearance of at least 1/16" (1/8" for 48" valve) must be provided between the collar and the bushing gland nut when valve is in the fully closed position.

Purchase Specifications

The assembly shall be bracket-mounted to exterior of an adapter attached to the center of the main valve cover. A stainless steel actuating stem with a swivel adapter shall be fastened directly to the main valve stem and move vertically through an adapter and gland with two O-ring seals as the valve moves. An adjustable collar located on the actuating stem shall actuate the sensor arm of a switch when valve has fully reached the open or closed (specify) position. The rotary-type position sensor arm shall actuate SPDT or DPDT type (specify) micro-switches mounted inside protective housing either weather-tight or explosion-proof NEMA rated (specify).

Provisions shall be made for bleeding air from valve cover through a small bleed screw and washer located on one wrench flat of adapter. All assemblies shall be capable of accommodating up to three switches. Standard materials in contact with operating fluid are brass, stainless steel, Monel and Buna-N.

A conduit hub opening in the switch enclosure shall be provided for attaching protective weatherproof conduit for the electrical switch wires (wiring and conduit supplied by others). A sealing plug shall be provided to protect conduit opening during shipping or storage.




X105 Series Dimensions (In Inches)


BasicValve 100-01	1 1/4	1 1/2	2	2 1/2	3	4	6	8	10	12	14	16	18	20	24	30	36*	42*	48*
Dimension "A"	10.19	10.19	7.16	7.16	7.34	7.00	6.69	6.91	9.88	9.59	9.16	10.78	10.78	18.23	19.10	35.07	36.07	36.07	36.07
Dimension "B"							1.69	1.69	2.44	2.94	2.94	2.94	2.94	4.32	5.19	8.40	8.40	8.40	8.40
C (NPT)	1/4	1/4	1/2	1/2	1/2	3/4	3/4	1	1	1 1/4	1 1/2	2	2	3/4	3/4	2	2	2	2
BasicValve 100-20					3	4	6	8	10	12	14	16	18	20	24	30	36*	42*	48*
Dimension "A"					7.16	7.34	7.00	6.69	6.91	9.88	9.59	9.59	10.78	10.78	10.78	11.30	35.07	36.07	36.07
Dimension "B"								1.69	1.69	2.44	2.94	2.94	2.94	2.94	2.94	5.19	8.40	8.40	8.40
C (NPT)					1/2	1/2	3/4	3/4	1	1	1 1/4	1 1/4	2	2	2	1	2	2	2




X105L

Limit Switch Assembly






Item	Part Number	Description	Valves Sizes Used On
1-2	20441701E	Collar W/Set Screw	All
3	67578-21B	Screw, Machine (2)	All
4	67584-23F	Washer, Lock (2)	All
5	34637K	Switch Assembly, Weather Proof	All
	34633J	Switch Assembly, Explosion Proof	All
6	64310G	Bracket Switch Mounting	10" thru 16"
7	67815-06J	Nut, Jam	All
8	63674G	Plate, Mounting	All
9	2838201J 2838202G	Adapter Adapter	2" thru 3" 4" thru 16"
10	63398C	Bushing, Gland	All
11	00951E	O-Ring (2)	All
12	6764417K 6764418H 6764419F 6764491J	Bushing Bushing Bushing Bell Reducer	8" and 10" 12" 14" 16"
13	8970101F 8970102D 8970103B 8970104K 8970105G	Stem, Actuating Stem, Actuating Stem, Actuating Stem, Actuating Stem, Actuating	2"-2 1/2" 3"-4" 6"-8" 10"-12"-14" 16"
15	6551201H	Fiber Washer	All
16	6824421K	Screw 8-32 x 3/8	All




When ordering parts, please specify:

- · Item Number
- Description
- Part Number

Typical Applications



Used for any electrical operation which can be performed by either opening or closing a switch; such as alarm systems, process control, pump control, motor starting or stopping, etc. Readily attached to most Cla-Val Valves.



The X105L Series Limit Switch Assembly is used on Cla-Val 60 Series Booster Pump Control Valves. Flexible conduit is used for electrical connections to the solenoid control and the limit switch.

Specifications

Materials: Aluminum switch housing

Steel bracket and brass adapter

Stainless steel stem

Electrical: 1/2" Conduit connection

Switch Type: SPDT UL, File No. E12252,

CSA Certified, File No. LR57325

Weather proof NEMA 1,3,4, and13

Switch Rating: UL/CSA rating: L96

15 amp. 125, 250, or 480 volts AC

1/2 amp. 125 volts DC 1/4 amp. 250 volts DC

Switch Options: DPDT switches available on request

UL/CSA Rating: L59, 10 amps

Explosion proof micro switches are

NEMA 1,7, and 9

UL Listed, File No. E14274 and CSA Certified, File No. LR57324: Class I, Group C and D and Class II, Group

E, F and G.

When Ordering, Please Specify

- Valve Size and Basic Valve Model
 Number
- 2. Catalog Number from Table Below
- 3. All Valve Name Plate Data
- 4. Select Single or Double Pole Switch
- 5. Explosion Proof or Weather Proof Type Enclosure
- 6. Amperes and Voltage, AC or DC
- Actuating Position (Valve Open or Closed)

CATALOG NO.	ACTUATION POSITION	SWITCH ENCLOSURE
X105LCW	Valve	Weather Proof
	Closed	
X105LCX	Valve	Explosion Proof
	Closed	
X105LOW	Valve	Weather Proof
	Open	
X105LOX	Valve	Explosion Proof
	Open	
X105L2W	Dual	Weather Proof
X105L2X	Dual	Explosion Proof



CLA-VAL

1701 Placentia Avenue • Costa Mesa, CA 92627

800-942-6326 • Fax: 949-548-5441 • Web Site: cla-val.com • E-mail: info@cla-val.com

CLA-VAL CANADA 4687 Christie Drive Beamsville, Ontario Canada LOR 1B4 Phone: 905-563-4963 E-mail sales@cla-val.ca CLA-VAL EUROPE
Chemin des Mésanges 1
CH-1032 Romanel/
Lausanne, Switzerland
Phone: 41-21-643-15-55

E-mail: cla-val@cla-val.ch

CLA-VAL UK
Dainton House, Goods Station Road
Tunbridge Wells
Kent TN1 2 DH England
Phone: 44-1892-514-400
E-mail: info@cla-val.co.uk

CLA-VAL FRANCE
Porte du Grand Lyon 1
ZAC du Champ du Périer
France - 01700 Neyron
Phone: 33-4-72-25-92-93

CLA-VAL PACIFIC
45 Kennaway Road
Woolston, Christchurch, 8023
New Zealand
Phone: 64-39644860
www.cla-valpacific.com
E-mail: info@cla-valpacific.com



Part

Number

20441701E

67578-21B

67584-23F

34637K

34633J

64310G

63674G

67815-06J

2838201J

2838202G

63398C

00951E

67644-17K 67644-18H

67644-19F

67644-91J

89701-01F

89701-02D

89701-03B

89701-04K

89701-05G

6551201H

6824421K

Bracket

Nut, Jam

Adapter

Adapter

Bushing

Bushing

Bushing

Item

1-2

3

4

5

6

7

8

9

10

11


12

13

15

X105L

Limit Switch Assembly






-MODEL - CDC-1

Check Valve (Sizes 3/8" and 1/2")




- **NSF 61 Approved**
- Meets low lead requirements
- · Soft Seat for Bubble Tight Shutoff, Spring Loaded for **Fast Seating Action**
- **Compact Design**
- Low Cracking Pressure 1/2 psi
- Flow Profile Designed to Minimize Head Loss
- Perfect Seating both at High and Low Pressure, Wide Temperature Range: +10° to 210°F
- · Polyethermide Disc to ensure the Best Resistance for **Corrosion and Abrasion**
- Patented Disc Guide to Prevent Any Side Loading



Full Open Operation

Item	Description	Material
1	Body	Brass
2	End Connection	Brass
3	Disc	Polytherimide
4	Seat	NBR
5	Spring	Stainless Steel


Available only in replacement assembly.




Tight Closing Operation

Dimensions

Size (NPT	Stock Number	A	В	С	Ι	СУ	psi	Wt.
3/8"	9834501A	1.73	0.79	1.06	0.40	4.55	400	0.37
1/2"	9834502J	2.32	0.98	1.35	0.53	6.00	400	0.32







THIS DATAWNS IS THE PROPERTY OF COAP-VAL ON AND SAME AND COPIES MADE INEXEST, IF ANY, SHALL BE REIONAGE FOR DEBMAND, DELIVERY AND DISCUSSAR, REACH AND DISCUSSAR, PARES SOLELY OF VICANOMINE AND ANY MANDER TO ANYONE FOR ANY PURPOSE, EXCEPT AS HEREIN AUTHORIZED, WITHOUT PRIOR WRITTEN APPROVAL OF CLA-VAL CO. THIS DRAWING IS SUBMITTED CONFIDENTIALLY AND MAY NOT BE USED IN THE MANUFACTURE OF ANY MATERIAL OR PRODUCT OTHER THAN SUCH MATERIALS AND PRODUCTS FUNNISHED TO CLA-VAL CO. WHETHER OR NOT THE EQUIPMENT OR INFORMATION SHOWN HEREON IS PATENTED OR OTHERWISE PROTECTED, FULL TITLE AND COPYRIGHTS, IF ANY, IN AND TO THIS DRAWING AND/OR INFORMATION DELIVERED OR SUBMITTED ARE FULLY RESERVED CLA-VAL CO."




Globe and Angle Needle Valves—CN Series





CAT. NO. CNB GLOBE

WHEN USED AS A CONTROL VALVE, HANDWEEL IS REMOVED AND STEM IS SLOTTED FOR SCREW-DRIVER ADJUSTMENT.



3/4" SIZE ONLY

When ordering parts, please specify:

- All nameplate data
- Description
- Part Number
- · Item Number
- Material

Item	Description
1. 2. 3. 4. 5. 6. 7.	Body Bonnet Stem Gland Nut Handwheel Nut Packing



 $- \, \mathsf{MODEL} - X46$

Flow Clean Strainer





- Self Scrubbing Cleaning Action
- Straight Type or Angle Type

The Cla-Val Model X46 Strainer is designed to prevent passage of foreign particles larger than .015". It is especially effective against such contaminant as algae, mud, scale, wood pulp, moss, and root fibers. There is a model for every Cla-Val. valve.

The X46 Flow Clean strainer operates on a velocity principle utilizing the circular "air foil" section to make it self cleaning. Impingement of particles is on the "leading edge" only. The low pressure area on the downstream side of the screen prevents foreign particles from clogging the screen. There is also a scouring action, due to eddy currents, which keeps most of the screen area clean.

D

1-3/4

2-1/4

2-1/2

2-1/2

3

3-3/8

4

4-1/4

4-1/2

4-1/4

B (NPT)

1/8

1/4

3/8

1/2

1/2

3/4

3/4

1

1

A (NPT)

1/4

3/8

3/8

1/2

3/8

3/4

1

1/2

X46A Straight Type A (In Inches)

Ε

3/4

1

1

1-1/4

1-1/4

2

2

2-3/4

2-3/4

2-3/4

G

1/2

3/4 3/8

7/8 1/2

7/8 3/4

1-1/8

1

1-1/2 7/8

1-3/8 7/8

1-3/4 7/8

1-3/8 7/8

1/2

3/4

7/8

1/2

1

1/2

1

1/2

1-1/4


1/2

1/4

3/4

7/8

Dimensions (In Inches)



A46 Angle Type B (In Inches)						
B(NPT)	C(S	AE) D	Е	Н	I	
1/8	1/4	1-3/8	5/8	7/8	1/4	
1/4	1/4	1-3/4	3/4	1	3/8	
3/8	1/4	2	7/8	1	1/2	
3/8	3/8	1-7/8	7/8	1	1/2	
1/2	3/8	2-3/8	1	1-1/4	5/8	

When Ordering, Please Specify:

- Catalog Number X46
- Straight Type or Angle Type
- Size Inserted Into and Size Connection
- Materials

INSTALLATION

The strainer is designed for use in conjunction with a Cla-Val Main Valve, but can be installed in any piping system where there is a moving fluid stream to keep it clean. When it is used with the Cla-Val Valve, it is threaded into the upstream body port provided for it on the side of the valve. It projects through the side of the Main Valve into the flow stream. All liquid shunted to the pilot control system and to the cover chamber of the Main Valve passes through the X46 Flow Clean Strainer.

INSPECTION

Inspect internal and external threads for damage or evidence of cross-threading. Check inner and outer screens for clogging, embedded foreign particles, breaks, cracks, corrosion, fatigue, and other signs of damage.

DISASSEMBLY

Do not attempt to remove the screens from the strainer housing.

CLEANING

After inspection, cleaning of the X46 can begin. Water service usually will produce mineral or lime deposits on metal parts in contact with water. These deposits can be cleaned by dipping X46 in a 5-percent muriatic acid solution just long enough for deposit to dissolve. This will remove most of the common types of deposits. Caution: use extreme care when handling acid. If the deposit is not removed by acid, then a fine grit (400) wet or dry sandpaper can be used with water. Rinse parts in water before handling. An appropriate solvent can clean parts used in fueling service. Dry with compressed air or a clean, lint-free cloth. Protect from damage and dust until reassembled.

REPLACEMENT

If there is any sign of damage, or if there is the slightest doubt that the Model X46 Flow Clean Strainer may not afford completely satisfactory operation, replace it. Use Inspection steps as a guide. Neither inner screen, outer screen, nor housing is furnished as a replacement part. Replace Model X46 Flow Clean Strainer as a complete unit.

When ordering replacement Flow-Clean Strainers, it is important to determine pipe size of the tapped hole into which the strainer will be inserted (refer to column A or F), and the size of the external connection (refer to column B or G).



Cla-Val Gauge Option



Model X141 4" Pressure Gauge

- Liquid-Filled
- Dual Scale (PSI / BAR)
- Long Life Stainless Steel Construction
- Tamper-Resistant Design
- 2 ½" and 4" Diameter Sizes
- Isolation Valve Included

The Cla-Val Model X141 Pressure Gauge Option consists of glycerin-filled pressure gauges with the Cla-Val Logo and ¼" CK2 Bronze Isolation Valves on the main valve inlet and outlet. Cla-Val gauges are waterproof, shock resistant, and fully enclosed with a stainless steel case and bronze wetted parts. Ambient temperature ratings are -4 Degrees F to +140 Degrees F (-20 Degrees C to +60 Degrees C).

All gauges have dual scale (PSI/BAR) and are supplied with a 1/4" NPT bottom connection. Model X141 gauges are available installed on new valves and must be specified on the customer Purchase Order. Consult factory for other available materials.

Available Pressure Ranges

X141 Gauge Assembly (2 1/2" Diameter Dial)

Pressure Range*	Part Number
0 - 100 psi	20534302K
0 - 160 psi	20534311J
0 - 200 psi	20534303J
0 - 300 psi	20534304H
0 - 400 psi	20534305G

X141 Gauge Assembly (4" Diameter Dial)

Pressure Range*	Part Number
0 - 100 psi	20534307E
0 - 200 psi	20534308D
0 - 300 psi	20534309C
0 - 400 psi	20534310K

Typical X141 Installation



Typical Installation with two X141 Gauges



*Specify desired pressure range and valve location (inlet or outlet) on order.






X43

Strainer

ITEM	DESCRIPTION	MATERIAL	
1	Pipe Plug	Stainless Steel	
2	Strainer Plug	Stainless Steel	
3	Gasket	Fiber	
4	Screen	Stainless Steel	
5	Body	Stainless Steel	
No parts available. Replacement assembly only.			

Standard 60 mesh pilot system strainer for fluid service.

Size	Stock Number
3/8 x 3/8	8850604D





Cla-Val Product Identification

How to Order

Proper Identification


For ordering repair kits, replacement parts, or for inquiries concerning valve operation, it is important to properly identify Cla-Val products already in service by including all nameplate data with your inquiry. Pertinent product data includes valve function, size, material, pressure rating, end details, type of pilot controls used and control adjustment ranges.

Identification Plates


For product identification, cast-in body markings are supplemented by identification plates as illustrated on this page. The plates, depending on type and size of product, are mounted in the most practical position. It is extremely important that these identification plates are not painted over, removed, or in any other way rendered illegible.



This brass plate appears on altitude valves only and is found on top of the outlet flange.



This tag is affixed to the cover of the pilot control valve. The adjustment range appears in the spring range section.



This aluminum plate is included in pilot system modification kits and is to be wired to the new pilot control system after installation.



This brass plate appears on valves sized 21/2" and larger and is located on the top of the inlet flange.




These two brass plates appear on ³/₈", ¹/₂", and ³/₄" size valves and are located on the valve cover.



These two brass plates appear on threaded valves 1" through 3" size or flanged valves 1" through 2". It is located on only one side of the valve body.



This brass plate is used to identify pilot control valves. The adjustment range is stamped into the plate.



This brass plate is used on our backflow prevention assemblies. It is located on the side of the Number Two check (2" through 10"). The serial number of the assembly is also stamped on the top of the inlet flange of the Number One check.



HOW TO ORDER

Because of the vast number of possible configurations and combinations available, many valves and controls are not shown in published product and price lists. For ordering information, price and availability on product that are not listed, please contact your local Cla-Val office or our factory office located at:

P. O. Box 1325 Newport Beach, California 92659-0325 (949) 722-4800 FAX (949) 548-5441

SPECIFY WHEN ORDERING

- Model Number
- · Globe or Angle Pattern
- Adjustment Range (As Applicable)
- · Valve Size
- Threaded or FlangedBody and Trim Materials
- Optional Features
- Pressure Class

UNLESS OTHERWISE SPECIFIED

- · Globe or angle pattern are the same price
- · Ductile iron body and bronze trim are standard
- X46 Flow Clean Strainer or X43 "Y" Strainer are included
- CK2 Isolation Valves are included in price on 4" and larger valve sizes (6" and larger on 600 Series)

LIMITED WARRANTY

Automatic valves and controls as manufactured by Cla-Val are warranted for three years from date of shipment against manufacturing defects in material and workmanship that develop in the service for which they are designed, provided the products are installed and used in accordance with all applicable instructions and limitations issued by Cla-Val. Electronic components manufactured by Cla-Val are warranted for one year from the date of shipment.

We will repair or replace defective material, free of charge, that is returned to our factory, transportation charges prepaid, if upon inspection, the material is found to have been defective at time of original shipment. This warranty is expressly conditioned on the purchaser's providing written notification to Cla-Val immediate upon discovery of the defect.

Components used by Cla-Val but manufactured by others, are warranted only to the extent of that manufacturer's guarantee.

This warranty shall not apply if the product has been altered or repaired by others, Cla-Val shall make no allowance or credit for such repairs or alterations unless authorized in writing by Cla-Val.

DISCLAIMER OF WARRANTIES AND LIMITATIONS OF LIABILITY

The foregoing warranty is exclusive and in lieu of all other warranties and representations, whether expressed, implied, oral or written, including but not limited to any implied warranties or merchantability or fitness for a particular purpose. All such other warranties and representations are hereby cancelled.

Cla-Val shall not be liable for any incidental or consequential loss, damage or expense arising directly or indirectly from the use of the product. Cla-Val shall not be liable for any damages or charges for labor or expense in making repairs or adjustments to the product. Cla-Val shall not be liable for any damages or charges sustained in the adaptation or use of its engineering data and services. No representative of Cla-Val may change any of the foregoing or assume any additional liability or responsibility in connection with the product. The liability of Cla-Val is limited to material replacements F.O.B. Newport Beach, California.

TERMS OF SALE

ACCEPTANCE OF ORDERS

All orders are subject to acceptance by our main office at Newport Beach, California.

CREDIT TERMS

Credit terms are net thirty (30) days from date of invoice.

PURCHASE ORDER FORMS

Orders submitted on customer's own purchase order forms will be accepted only with the express understanding that no statements, clauses, or conditions contained in said order form will be binding on the Seller if they in any way modify the Seller's own terms and conditions of sales.

PRODUCT CHANGES

The right is reserved to make changes in pattern, design or materials when deemed necessary, without prior notice.

PRICES

All prices are F.O.B. Newport Beach, California unless expressly stated otherwise on our acknowledgement of the order. Prices are subject to change without notice. The prices at which any order is accepted are subject to adjustment to the Seller's price in effect at the time of shipment. Prices do not include sales, excise, municipal, state or any other Government taxes. Minimum order charge \$100.00.

RESPONSIBILITY

We will not be responsible for delays resulting from strikes, accidents, negligence of carriers, or other causes beyond our control. Also, we will not be liable for any unauthorized product alterations or charges accruing there from.

RISK

All goods are shipped at the risk of the purchaser after they have been delivered by us to the carrier. Claims for error, shortages, etc., must be made upon receipt of goods.

EXPORT SHIPMENTS

Export shipments are subject to an additional charge for export packing.

RETURNED GOODS

- Customers must obtain written approval from Cla-Val prior to returning any material.
- 2. Cla-Val reserves the right to refuse the return of any products.
- 3. Products more than six (6) months old cannot be returned for credit.
- 4. Specially produced, non-standard models cannot be returned for credit.
- Rubber goods such as diaphragms, discs, o-rings, etc., cannot be returned for credit, unless as part of an unopened vacuum sealed repair kit which is less than six months old.
- Goods authorized for return are subject to a 35% (\$100 minimum) restocking charge and a service charge for inspection, reconditioning, replacement of rubber parts, retesting, repainting and repackaging as required.
- Authorized returned goods must be packaged and shipped prepaid to Cla-Val, 1701 Placentia Avenue, Costa Mesa, California 92627.



CLA-VAL

PO Box 1325 Newport Beach CA 92659-0325 Phone: 949-722-4800 • Fax: 949-548-5441

CLA-VAL CANADA 4687 Christie Drive

Beamsville, Ontario
Canada L0R 1B4
Phone: 905-563-4963
Fax: 905-563-4040
«COPYRIGHT CLA-VAL 2011 Printed in USA
Specifications subject to change without notice.

CLA-VAL EUROPE

Chemin dés Mesanges 1 CH-1032 Romanel/ Lausanne, Switzerland Phone: 41-21-643-15-55 Fax: 41-21-643-15-50

www.cla-val.com

Represented By:



-MODEL- REPAIR KITS

Model 100-01 Hytrol Main Valve

	BUNA-N MATERIAL					
	RUBBER KIT REPAIR KIT REBUILD ASSEMBLY STUD & NUT KIT					
	STOCK NO.	STOCK NO.	STOCK NO.	STOCK NO.		
3/8"	9169801K		21176614B	21176633J		
1/2"	9169802H	21176602F	21176615A	21176634H		
3/4"	9169802H	21176602F	21176615A	21176634H		
1" Non-Guided	9169803F	21176601G	21176616K	21176636F		
1"	9169804D	21176603E	21176617J	21176636F		
1 1/4"	9169804D	21176603E	21176617J	21176636F		
1 1/2"	9169804D	21176603E	21176617J	21176636F		
2"	9169805A	21176608K	21176618H	21176637E		
2 1/2"	9169811J	21176609J	21176619G	21176638D		
3"	9169812G	21176604D	21176620D	21176639C		
4"	9169813E	21176605C	21176621C	21176640K		
6"	9169815K	21176606B	21176622B	21176641J		
8"	9817901D	21176607A	21176623A	21176642H		
10"	9817902B	21176610F	21176624K	21176643G		
12"	9817903K	21176611E	21176625J	21176644F		
14"	9817904H	21176612D	21176626H	21176645E		
16"	9817905E	21176613C	21176627G	21176645E		

Model 100-20 Hytrol Main Valve

BUNA-N MATERIAL							
	RUBBER KIT REPAIR KIT REBUILD ASSEMBLY STUD & NUT KIT						
	STOCK NO.	STOCK NO.	STOCK NO.	STOCK NO.			
3"	9169805A	21176608K	21176618H	21176637E			
4"	9169812G	21176604D	21176620D	21176639C			
6"	9169813E	21176605C	21176621C	21176640K			
8"	9169815K	21176606B	21176622B	21176641J			
10"	9817901D	21176607A	21176623A	21176642H			
12"	9817902B	21176610F	21176624K	21176643G			
14"	9817903K	21176611E	21176625J	21176644F			
16"	9817903K	21176611E	21176625J	21176644F			

Consult factory for larger sizes

Rubber Kit Includes: Diaphragm, Disc, Spacer Washers

Repair Kit Includes: Diaphragm, Disc, Spacer Washers, Epoxy Coated Disc Retainer, Epoxy Coated Diaphragm Washer,

Protective Washer

Rebuild Assembly Includes: Diaphragm, Disc, Spacer Washers, Epoxy Coated Disc Retainer, Epoxy Coated

Diaphragm Washer, Protective Washer, Stainless Steel Bolts & Washers (6" & Below), Stainless Steel Studs, Nuts, & Washers (8" & Above), Stem, Stem Nut, Disc Guide,

Standard Cover Spring, Cover Washer

Stud & Nut Kit Includes: Stainless Steel Bolts & Washers (6" & Below), Stainless Steel Studs, Nuts, & Washers (8" & Above)

Repair Kits for 100-02/100-21 Powertrol and 100-03/100-22 Powercheck Main Valves

For: Powertrol and Powercheck Main Valves-150 Pressure Class Only

Includes: Diaphragm, Disc (or Disc Assembly) and O-rings and full set of spare Spacer Washers.

Valve	Kit Stock Number	Valve	Kit Stock Number	
Size	100-02	Size	100-02 & 100-03	100-21 & 100-22
3/8"	9169901H	2½"	9169910J	N/A
1/2" & 3/4"	9169902F	3"	9169911G	9169905J
1"	9169903D	4"	9169912E	9169911G
1¼" & 1½"	9169904B	6"	9169913C	9169912E
2"	9169905J	8"	99116G	9169913C
		10"	9169939H	99116G
		12"	9169937B	9169939H

Larger Sizes: Consult Factory.

Repair Kits for 100-04/100-23 Hy-Check Main Valves

For: Hy-Check Main Valves—150 Pressure Class Only

Includes: Diaphragm, Disc and O-Rings and full set of spare Spacer Washers.

Valve	Kit Stock Number		Valve	Kit Stock Number	
Size	100-04	100-23	Size	100-04	100-23
4"	20210901B	N/A	12"	20210905H	20210904J
6"	20210902A	20210901B	14"	20210906G	N/A
8"	20210903K	20210902A	16"	20210907F	20210905H
10"	20210904J	20210903K	20"	N/A	20210907F
			24"	N/A	20210907F

Larger Sizes: Consult Factory.

Repair Kits for Pilot Control Valves (In Standard Materials Only)

Includes: Diaphragm, Disc (or Disc Assembly), O-Rings, Gaskets or spare Screws as appropriate.

BUNA-N® (Standard Material)				VITON (For KB C	Controls)
Pilot	Kit Stock	Pilot	Kit Stock	Pilot	Kit Stock
Control	Number	Control	Number	Control	Number
CDB	9170006C	CFM-9	12223E	CDB-KB	9170012A
CDB-30	9170023H	CRA (w/bucking spring)	9170001D	CRA-KB	N/A
CDB-31	9170024F	CRD (w/bucking spring)	9170002B	CRD-KB (w/bucking spring)	9170008J
CDB-7	9170017K	CRD (no bucking spring)	9170003K	CRL-KB	9170013J
CDH-2	18225D	CRD-18	20275401K	CDHS-2BKB	9170010E
CDHS-2	44607A	CRD-22	98923G	CDHS-2FKB	9170011C
CDHS-2B	9170004H	CRL (55F, 55L)	9170007A	CDHS-18KB (no bucking spring)	9170009G
CDHS-2F	9170005E	CRL60/55L-60	9170033G	102C-KB	1726202D
CDHS-3C-A2	24657K	CRL60/55L60 1"	9170042H		
CDHS-8A	2666901A	CRL-4A	43413E		
CDHS-18	9170003K	CRL-5 (55B)	65755B		
CDS-4	9170014G	CRL-5A (55G)	20666E		
CDS-5	14200A	CRL-18	20309801C		
CDS-6	20119301A	Universal CRL	9170041K		
CDS-6A	20349401C	CV	9170019F		
CFCM-M1	1222301C	X105L (O-ring)	00951E	Buna-N®	
CFM-2	12223E	102B-1	1502201F		
CFM-7	1263901K	102C-2	1726201F	CRD Disc Ret. (Solid)	C5256H
CFM-7A	1263901K	102C-3	1726201F	CRD Disc Ret. (Spring)	C5255K

Repair Assemblies (In Standard Materials Only)

•		
Control	Description	Stock Number
CF1-C1	Pilot Assembly Only	89541H
CF1-CI	Complete Float Control less Ball and Rod	89016A
CFC2-C1	Disc, Distributor and Seals	2674701E
CSM 11-A2-2	Mechanical Parts Assembly	97544B
CSM 11-A2-2	Pilot Assembly Only	18053K
33A 1"	Complete Internal Assembly and Seal	2036030B
33A 2"	Complete Internal Assembly and Seal	2040830J

When ordering, please give complete nameplate data of the valve and/or control being repaired. MINIMUM ORDER CHARGE APPLIES